

Complete Pond Kit

MODEL/MODELO #QCPK


REMINDER CALL 1-888-755-6750 BEFORE RETURNING TO STORE.





Questions, problems, missing parts? Before returning to your retailer, call our customer service department at 1-888-755-6750, 8 a.m.-6 p.m., EST, Monday-Friday.

PACKAGE CONTENTS

Part	Description	Quantity
Α	Pump	1
В	Adapter	1
С	Coupler	1
D	3-tier fountain head	1
Е	Extension tube	2
F	Fountain head base	1
G	Waterbell fountain head	1
Н	Trumpet fountain head	1
	Foam-jet fountain head	1
J	PVC pond liner (7 ft. x 10 ft.)	1
K	Floating Lilies	3
L	Rock lights w/ sensor	1
М	Transformer	1









WARNINGS AND CAUTIONS - PUMP

WARNING

- Risk of electrical shock. This pump is supplied with a grounding conductor and grounding-type attachment plug. To reduce the risk of electric shock, be certain that it is connected only to a properly grounded, grounding-type receptacle.
- Do not exceed the voltage shown on the pump.
- Always disconnect pump from the power source before beginning any maintenance or work on the pump.
- Inspect cord for damage before installation and/or maintenance. Replace the entire pump assembly if damage is found.
- Do not remove the grounding pin from the power cord plug.
- To reduce the risk of electric shock, use only on portable, self-contained fountains no larger than 5 ft. in any dimension.
- Risk of electrical shock This pump has not been investigated for use in swimming pools or marine areas.

CAUTION

- This pump has been evaluated for use with water only.
- Use a proper power source as indicated on the pump label.
- Keep the cord away from high temperatures or other heat sources.
- Do not pump heated liquids.
- Do not let the pump run dry. Pump must be completely submerged for proper operation and cooling.
- Operate in freshwater only. Avoid heavily chlorinated water and water with high pH levels.
- Do not lift the pump by its power cord.



WARNINGS AND CAUTIONS - STONE LIGHTS

WARNING

- To reduce the risk of electrical shock, connect only to a properly grounded, grounding-type receptacle (GFCI).
- Do not exceed the voltage shown on the transformer.
- Do not submerge the transformer.
- To reduce the risk of fire or injury, keep lamp away from materials that may burn.
- Always disconnect light from the power source before beginning any maintenance or work on the light.
- Inspect cord for damage before installation and/or maintenance. Replace the entire light/transformer assembly if damage is found.

CAUTION

- Use a proper power source as indicated on the transformer label.
- Keep the cord away from high temperatures or other heat sources.
- Do not lift the light or the transformer by its power cord.
- This light assembly is not intended for use in swimming pools or hot tubs.

PREPARATION - PUMP & STONE LIGHTS

Before beginning assembly or operation of product, make sure all parts are present. Compare parts with package contents list and diagram above. If any part is missing or damaged, do not attempt to assemble, install or operate the product. Contact customer service for replacement parts.

- Estimated Assembly Time: 5 minutes
- No tools required for assembly.

PREPARATION – LINER

Before installing your pond liner, make sure it is in good condition with no tears or holes. If you find any damage, do not attempt to install the liner. Contact customer service for a replacement.

- Estimated Assembly Time: 2 hours
- Tools Required for Assembly: Sand, Shovel.

Calculate the dimensions of your pond. Your pond should be at least 18 in. deep at the deepest point. Allow for a 10 in. overlap around the perimeter of the pond. The 7 ft. x 10 ft. liner will create a pond that is approximately 3 ft. x 6 ft. x 18 in. deep. It will hold approximately 200 gal. of water.

INSTALLATION INSTRUCTIONS – LINER

1. Use sand to mark the outline of your pond. Fig. 1




Fig. 1

 Dig out your pond and remove any debris or rocks that might damage your liner. Add approximately 2 in. of sand to the pond area. The sand functions as a cushion beneath your pond liner. Spread the sand over the entire area and compact it. Fig. 2




Fig. 2

3. Open the liner and drape it across the pond area, making sure to leave at least 10 in. of overlap around the perimeter of the hole. Begin to fill the pond with water, smoothing out any wrinkles as you do this. Fig. 3




Fig. 3

4. When the pond is full, bury the excess liner in a small trench around your pond with stones and rocks, according to your landscape design. Fig. 4




Fig. 4

ASSEMBLY INSTRUCTIONS - FOUNTAIN HEAD KIT

1. Connect the two extension tubes with the coupler. Fig. 5




Fig. 5

2. Choose a fountain head for the desired water effect, and assemble your choice as shown in Fig. 6




Fig. 6

3. Install the stabilizers onto the bottom of the pump. Fig. 7




Fig. 7

4. Insert the assembled fountain head kit onto the outlet of the pump using the adaptor supplied in the kit. Fig. 8




Fig. 8

5. Place the pump into the water and connect to a proper power source. Fig. 9




Fig. 9

ASSEMBLY INSTRUCTIONS - STONE LIGHTS

1. Connect the sensor to the transformer by pushing the plug into the transformer socket until it is firmly seated. Hand tighten the nut from the plug to the socket. Fig. 10




Fig. 10

2. Place the lights in or out of the water. Make sure that the transformer and sensor are NOT submerged. Make sure that the light sensor faces up. Fig. 11

NOTE: At night, the lights will automatically turn on. At sunrise, they will automatically turn off.




Fig. 11

3. Plug the transformer into a properly grounded electrical outlet. Fig. 12




Fig. 12

CARE AND MAINTENANCE - PUMP

- Keep water clean to prolong the life of the pump. Use of distilled water will reduce mineral deposits.
- Regular cleaning of the pump may be necessary depending upon the environment in which it is operated. Clean the pump when it is visibly soiled or when a drop in performance is detected.
- Before cleaning, always disconnect the pump from the power source.
- Remove all parts from the pump and clean in warm, soapy water.
- Disassemble the pump housing and remove the impeller housing to expose the impeller assembly. Remove the impeller assembly by gently pulling on the impeller blades. Use a soft cloth or brush to clean the impeller assembly and the inside of the impeller housing.

TROUBLESHOOTING - PUMP

If the pump fails to operate:

- Check to make sure the power cord is plugged in and the pump is getting power.
- Check the pump outlet and any tubing, fountains, spitters etc. for kinks or obstructions.
- Remove the inlet screen and/or pump cover, and impeller housing to expose the impeller. Turn the impeller to ensure that it is not broken or jammed.

If the performance of the pump is not satisfactory or the pump does not flow evenly:

- Check to make sure the pump is completely submerged in water.
- Check to make sure the impeller and the housing are clean.
- Adjust flow control.

CARE AND MAINTENANCE - STONE LIGHTS

- Periodically, your lights may require cleaning for optimal performance.
- Cleaning should only be done with warm soapy water. Be sure to use biodegradable soap.
- The frequency of cleaning depends upon the conditions of the environment where lights are used.


TROUBLESHOOTING - STONE LIGHTS


- If lights fail to illuminate, check that lights are getting power by testing another appliance in the same power outlet.
- The light is designed to turn on when it gets dark, and turn off when it gets light. To activate the light during daylight hours, cover the sensor.
- If lights do not turn off during daytime, check sensor. Make sure the sensor faces up and is not covered by dirt or debris.


REPLACEMENT PARTS LIST

For replacement parts, call our customer service department at 1-888-755-6750, 8 a.m.-6 p.m., EST, Monday-Friday.

Part	Description	
В	Adapter	
С	Coupler	
D	3-tier fountain head	
Е	Extension tube	
F	Fountain head base	
G	Waterbell fountain head	
Н	Trumpet fountain head	
I	Foam-jet fountain head	
L	Rock lights w/ sensor	
M	Transformer	
N	Front Cover	
0	Locking ring	
Р	Impeller cover	
Q	Large o-ring	
R	Shaft support	
S	Impeller assembly	
Т	Shaft	
U	Stabilizers	







All pumps and electrical products are warranted to the user against defective material and workmanship, under normal working conditions. This warranty period begins on the date of purchase by the original purchaser.

All Gardenique™ electrical products are warranted to the user against defective material and workmanship, under normal working conditions for 1 year from the date of purchase. All Gardenique™ liners are warranted to the user against defective workmanship, under normal working conditions for 20 years from the date of purchase. All other Gardenique™ product is warranted to the user against defective material and workmanship, under normal working conditions for 90 days.

Application

Warranty covers only properly installed and maintained units. Pump warranty is limited to applications pumping fresh water in a pond or fountain only. Other liquid applications or extreme temperature uses must be approved in writing by the manufacturer. Receipt and product date code are required for warranty claims.

Warranty Claim

<u>Warranty claims must be made by calling customer service (at 1-888-755-6750).</u> If the item is determined to be defective, you will be given authorization to return the defective part(s), <u>freight pre-paid</u>, along with <u>proof of purchase</u>.

Disposition

The manufacturer will make a good faith effort for prompt disposition regarding all warranty claims. Returned product will be inspected to determine cause of failure before warranty is applied. Warranty does not cover any costs associated with the shipping, handling, installation or removal of products or parts subject to this warranty. For products damaged in transit, a claim should be filed with the carrier.

Disclaimer

Any oral statements made about the product by the seller, the manufacturer, the representatives, or any other parties do not constitute warranties, should not be relied upon by the user, and are not part of the contract for sale. The seller's and manufacturer's only obligation, and buyer's only remedy shall be for the manufacturer to either replace and/or repair at the manufacturer's sole discretion, the product as described above. Neither seller nor the manufacturer shall be liable for injury, loss or damages for lost profits, lost sales, injury to person or property, or any other incidental or consequential loss arising from any cause whatsoever, no matter whether based upon warranty, contract, negligence or other misuse, and the buyer and user agree that no other remedy shall be available to them. Before using, the buyer and user shall determine the suitability of the product for the intended use, and assume all risk and liability whatsoever in connection therewith. The warranty and remedy described in this limited warranty is an exclusive warranty and remedy in lieu of any other warranty or remedy expressed or implied. All other warranties and remedies are hereby expressly excluded, including but not limited to any implied warranty of merchantability of fitness for any particular purpose. This warranty gives the buyer and user specific legal rights, and buyer and user may also have other rights which vary from state to state. Some states do not allow exclusions or limitations of incidental or consequential damages, so the above limitations or exclusions may not apply to you.

